

Piping Paste Ornaments

1. Cut colored glass slightly larger than the clear dimensions below.
2. Place WLPF in 1 oz Piping Bottle (PIPKIT4 available on the CFE website)
3. Pipe with White Low-Fire/No-Fire piping paste on clear glass.
(Kits available on the CFE website that have paste, brush and piping bottles)
4. Add dots of G310 Vermilion and GS-502 Copper Sparkle (mixed with GM300)
5. Place piped piece on another piece of glass (I used 96 coe Opal Art)
6. Fire to 1400 with 10 minute hold to leave the smaller piece on the top rounded but dimensional.

