

## <u>Iris in Red</u>

By: Paula McCoy © 2006

- 1. On greenware earthenware (04/06) vase, apply 4 coats of **CS612 Red Alert** to entire vase.
- 2. Fire to witness cone 04.
- 3. Roll glaze the inside of vase with **CGE501 Black Patent**, slightly thinned down.
- 4. If any areas are not covered well apply 2 more coats of Red Alert. Allow to dry and transfer pattern, alternating the 2 Iris around the vase. Depending on the size of vase you may have to add additional leaves for fillers between flowers.
- With #10 or #12 Square shader, water load and corner load with CC101 Cobalt Black and float this color here and there adding shadows, dividing leaves, petals, etc. Refer to photo for placement.
- With #4 and #1 Liner brush and CC101 Cobalt Black detail and outline with thick and thin lines.
- With pencil create a wavy top around design. Block in 2 coats of CC101 Cobalt Black in this area. Allow to dry. Apply 2 coats of CGE501 Black Patent glaze over the same areas.
- 8. Because of the Black Patent glaze at the top you will only need to apply 1 coat of clear in that area but the rest of the vase will require 2 coats of CSP01 Gloss Medium NT Clear Glaze.
- 9. Stilt and fire to witness cone 06.

Colors for Earth, LLC
Weatherford, TX 76085
817-677-5020
www.colorsforearth.com
info@colorsforearth.com
Or ceramicsbypaula@gmail.com



